




PLATINUM ACCESS SYSTEMS, INC.

# Quick Installation Steps for BLSW814 and BLSW1016 Operator

1. Please mount the operator like it shown in the concrete pad drawing (See Page 15 in manual).
2. Put the Arm on the gate like shown on page 14 in the manual
3. Turn the Motor Breaker switch to OFF position. Then manually push and pull the gate to adjust the limit CAM to set the limit OPEN position and Limit CLOSE position for the swing gate (See Page 20 in the manual).
4. Once you have set the limit CAM positions. You can turn the Motor breaker back to be ON position.
5. Make sure the operator Power A/C switch is OFF. Then connect the AC Power Source wires to the operator Power Input wires. White to White, Black to Black, and Green to Green (**Operator must be grounded to the earth to protect the operator from lightning**).
6. Now you can hook up the remote control receiver, keypad, or the other input devices to the main boards (See page 24 and 25 in manual for Keypad and radio Receiver connection).
7. Turn On the operator Power A/C switch. Then press RESET button and hold it for about 5 seconds.
8. Then press OPEN, or CLOSE button on the main board to check if you have set the Close Limit position and Open Limit position correct, or not. Now you can use the OPEN and CLOSE switches on the main board, or the remote control to help to set the limit CAM correctly if need.
9. Set the Sensitivity correctly (Default setting is set between 2 and 3 O'clock. See page 29 for the location of the location of the Gate SNS pot).
10. Set the TIMER to the way that you wanted (see page 29 for the location of the TIMER Pot).
11. Set the P/S SYNC if need for Primary, and Secondary gates (See page 29 for the location of the P/S SYNC pot).
12. Once you have confirmed the limit CAM have set correctly. Press and hold the RESET button for 5 seconds (If there this is a Master/Slave system. Then you need to rest the Slave unit first. Then reset the master unit).
13. Then Press Open, or Close button once, or use the remote control to let the gate to learn again to confirm the OPEN and CLOSE limit CAM positions.( The gate should not hit anything like the wall, or the pole when the gate is at fully open position, or at fully close position).
14. Now the gate is ready for normal operation.



## PLATINUM ACCESS SYSTEMS, INC.

1725 E. Grevillea Court, Ontario, CA 91761 | Sales: (909) 259-6005 | Fax: (909) 923-7890 | [www.platinumasi.com](http://www.platinumasi.com)

Technical Support (909) 259-6001 | Email: [sales@platinumasi.com](mailto:sales@platinumasi.com) | [techsupport@platinumasi.com](mailto:techsupport@platinumasi.com)